


Han River Flood Control Office (Ministry of Land, Infrastructure and Transport)

Korea Institute of Civil Engineering and Building Technology (KICT)

DWAT



DWAT (Dynamic Water resources Assessment Tool) – User’s Manual 1.0

October 2016

For Software version 1.0 Beta

Han River Flood Control Office (HRFCO)



Korea Institute of Civil Engineering and Building Technology (KICT)



Authors:

Sung KIM	KICT
Cheolhee JANG	KICT
Hyeonjun KIM	KICT
Hyoseob Jo	HRFCO
Hwirin KIM	HRFCO

Please refer this technical manual as:

KIM, S., JANG, CH., KIM, HJ., JO, HS and KIM, HR. (2016). DWAT – User’s manual v1.0

Foreword

DWAT is a software to analyze water cycle for a watershed or water management unit with runoff, evapotranspiration, water use and water supply in aspect of space and time. DWAT uses a distributed conceptual scheme for water cycle analysis and can be used with or without observed data. As the system is linked to an open GIS tool, physical input parameters can be searched and optimized conveniently. DWAT has been developed since 2008 as a part of WMO (World Meteorological Organization) RA (Regional Association) II WGHS (Working Group on Hydrological Services) activities, and it has been supported by the Han River Flood Control Office, Ministry of Land Infrastructure and Transport, Republic of Korea.

The global analysis of a hydrologic-hydraulic network is essential in numerous decision-making situations such as the management or planning of water resources. DWAT makes such analyses accessible to a broad public through its user-friendly interface and its valuable possibilities.

DWAT contains sub-algorithms such as evapotranspiration, infiltration, watershed runoff, groundwater movement and channel routing. The model is under verification through applications to various rural and forest catchments and new urban development regions in Korea. The model reliability will be strongly enhanced through the further model applications to global area.

The DWAT was developed in a “node-link type” that enables objective considerations of runoff characteristics resulting from different geomorphological factors by dividing ranges into sub-catchments judged to be hydrologically homogenous. The user interface of the model was developed for easy access and operation of the model and it will help how to use the model to effectively simulate and analyze many scenarios simultaneously.

The purpose of this user guide gives instruction on how to use the DWAT. When using the program, please check the content of this user guide.

Copyright © 2016 KICT & HRFCCO

The copyright of the DWAT is reserved by KICT & HRFCCO.

Any commercial use or unauthorized reproduction of the program and the user manual are strictly prohibited.

KICT & HRFCCO accept no responsibility and exclude all liability whatever in respect of the program and any person's use or reliance on any information of this publication.

For any further information on this program including technical issues and questions regarding to the use of the program, please contact researchers and development team.

October, 2016

■ Research/Development team

Hydro Science and Engineering Research Institute, Korea Institute of Civil Engineering and Building Technology, 283 Goyangdae-ro, Ilsanseo-gu, Goyang-si, Gyeonggi-do, 411-712, Republic of Korea.

- Team leader: Sung, KIM(skim@kict.re.kr), Ph.D, Senior Research Fellow

- Researchers: Cheolhee, JANG(chjang@kict.re.kr), Hyeonjun, KIM(hjkim@kict.re.kr)

TEL.: 82-31- 910-0745

Index

- Foreword..... 3

- Chapter 1: Introduction..... 8
 - 1.1 System Requirements..... 8
 - 1.2 Installation procedure..... 9

- Chapter 2: Model Interface 12
 - 2.1 Main Menu..... 14
 - 2.1.1 File..... 15
 - 2.1.2 Edit..... 17
 - 2.1.3 View..... 17
 - 2.1.4 GIS Preprocessor..... 18
 - 2.1.5 Model..... 29
 - 2.1.6 Help..... 31
 - 2.2 Icons..... 31
 - 2.3 Property view..... 31

Chapter 3: Model Input Data.....	32
3.1 Subject Catchment.....	36
3.1.1 Background Image.....	36
3.2 Climate.....	37
3.2.1 Climate Data Import.....	38
3.2.2 Climate Data Checking.....	40
3.2.3 Climate Node Entry.....	42
3.3 Ground Surface.....	49
3.3.1 Catchment Node Entry.....	50
3.3.2 Parameter Entry.....	50
3.4 Soil.....	52
3.4.1 Parameter Entry.....	53
3.5 River.....	56
3.6 Groundwater Aquifer.....	56
3.6.1 Aquifer Specification Entry.....	57
3.6.2 Groundwater Movement Parameter Entry.....	58
3.7 Reservoir.....	59

3.8 Wetland.....	63
3.9 Recycle.....	65
3.10 Import.....	67
3.11 Channel Routing (Link)	69
3.12 Junction and Outlet.....	72
3.12.1 Junction.....	72
3.12.2 Outlet.....	73
Chapter 4: Model Running.....	75
4.1 Analysis Condition Setting.....	75
4.2 Model Execution.....	76
Chapter 5: Analysis of Results.....	77
5.1 Water Balance.....	79
5.2 Chart.....	81
5.3 Table.....	84
References.....	85

Chapter 1: Introduction

This user guide provides instruction on how to use DWAT and assists water resources engineers and researchers to easily understand the program and to increase the ability to apply the program to fields.

This chapter includes introduction to program installation and its interface. In addition, all the processes to create, extract and correct input data are explained in detail and the methods to execute the model and analyze various figures and graphs are explained.

However, the configurations of the model described in this user guide are those for the current version and they may be changed with further development. Characteristics of DWAT are summarized as follows:


- Physical parameter-based link-node type model
- Separate runoff simulations for pervious and impervious zones
- Analysis of infiltration, evaporation, groundwater flows relative to soil layers and groundwater aquifers and simulations of channel routing
- Simple, practical and easily accessible
- Guaranteed satisfactory results with minimal data and efforts
- Easy user convenience system (GUI)
- Provision of results through diverse tables and figures

1.1 System Requirements

In order to use the DWAT program, at least 100Mb are required as the minimum available disk space. The minimum requirements for a PC system are summarized in the following table.

System	Minimum	Recommended
Operation systems	Windows 98, Windows ME, Windows XP, Windows 2000, Windows Vista, Windows 7, Windows 8, Windows 10	
Memory	512MB	1GB
CPU	P-4, 1.5Hz processor	P-4, 3.0Hz processor Core2 2.0 processor
Hard disk capacity	100Mb extra space	500Mb extra space


1.2 Installation procedure




You install the DWAT by double-clicking on the **DWATSetup.msi** file in the installation directory.




When the 'DWAT Setup screen' appears, click **Next**.




The DWAT install defaults to installing the program in C:\Program Files\DWAT and users can create their own directory structure. Once you've designated the directory to which the program will be installed, click **Next**.



In the 'installation confirmation screen', click **Next**.



The 'Program installation screen' will appear. If you click the cancel button, the program installation will not be completed. Please wait until the 'Installation completion screen' appears.



When the 'Installation completion screen' has appeared, click **Finish**.
The DWAT program has been successfully installed.


You may check the installation in the 'Program Start Menu'.

Windows start menu > program > DWAT > DWAT

Chapter 2: Model Interface

The interface of the model has been developed so that it can be easily applied and managed by users and so that various scenarios can be easily applied. The user interface has been designed so that all input/output data are linked with Microsoft Excel. All data sets are easily managed in each project. The environment used in developing the user convenience system (Graphic User Interface, GUI) is Microsoft Visual Studio and the system was developed for Windows.


Figure 2.2-1 shows the basic configuration screen of the DWAT. The main screen of the DWAT is primarily divided into the Main Interface, Parameters and Node. The tools are used in analysis and include the Main Menu and Toolbar, Node, etc. The Parameters window indicates the attributes of nodes and the variables of selected nodes.



<Figure 2.2-1> Basic configuration screen of the CAT

2.1 Main Menu

The DWAT has six main menu items and they are shown in Figure 2.2-2. The main menu provides overall operation functions, including project file management, model executions and input/output result checking.




<Figure 2.2-2> DWAT main menu

The functions of each menu are reviewed in the following sections.

2.1.1 File

New Project: This is a menu to create new projects. This menu clears all data in memory and interface fields and opens an empty project.

Open Project: This is a menu to display the standard file open dialog. It allows users to open existing projects stored in the certain directory and is mainly used to revise existing data in the project. The extension of the project files of the DWAT is ***.dpr** and only project files (*.dpr) can be opened.




Save: It allows you to save the current .cpr file (including all screens, attribute information and data of the open project).


Save as: It allows users to save the current project under another name.

Save result: It allows users to save simulation result of the current project under another name.

Background: Background images (*.bmp or *.jpg) can be imported. This may be useful for configuring each source node and link on the background (e.g. the watershed boundaries and rivers).



Create Series: This menu creates time series (e.g. rainfall, meteorological data and observed discharges) into input data files (*.dat) in the DWAT.



2.1.2 Edit

Edit menu has various functions. These are briefly described below.

Undo: a function to undo after editing

Cut: a function to remove attribute tables, links and nodes

Copy: a function to reproduce attribute tables, links and nodes


Paste: a function to paste attribute tables, links and nodes

Delete: a function to delete attribute tables, links and nodes


2.1.3 View

View menu has various functions. These are briefly described below.

Toolbar: a function to show or hide the tool bar on the bottom of the main menu



Status bar: a function to show or hide the display window on the bottom of the CAT program window




Pan: a function to pan the entire configuration screen

Zoom in: expanding function (interlocked with mouse scrolls)

Zoom out: reducing function (interlocked with mouse scrolls)

Series: functions to display the time series input data recreated in the DWAT; check, edit and save data files from model outputs; export the files as text (*.txt) files (since all files created in the DWAT are

stored in the form of data files, *.dat (binary type format), this is a function to facilitate users' checking.).



2.1.4 GIS Preprocessor

Hydrologic models like DWAT require land use and soil data to determine the area and the hydrologic parameters of each land-soil category simulated within each sub-watershed.

The physical parameters of the system can be searched and optimized conveniently using GIS Preprocessor menu. This tool allows users to load land use and soil themes into the current project and determine the land use/soil class combinations and distributions for the delineated watershed and each respective sub-watershed.



Watershed delineation is one of the most commonly performed activities in hydrologic analyses. Digital elevation models (DEMs) provide good terrain representation from which watersheds can be derived automatically using GIS technology.

The complete process of watershed delineation and input parameters using GIS Preprocessor involves a sequence of steps

1. It is important to use a DEM with no depressions or sinks, so we first have to “fill” the DEM.
 - To create an accurate representation of flow direction and, therefore, accumulated flow, it is best to use a dataset that is free of sinks. A digital elevation model (DEM) that has been processed to remove all sinks is called a depressionless DEM. The identification and removal of sinks, when creating a depressionless DEM, is an iterative process. When a sink is filled, the boundaries of the filled area may create new sinks that need to be filled.


2. Determining the slope direction at each pixel, i.e. the “aspect” of the terrain.
3. Determining the “flow accumulation”, that is, the number of up gradient pixels that slope toward each point in the DEM grid.
4. Calculation of preliminary stream network raster using a flow accumulation.
5. Add a point that represents the outlet of watershed. You need to add and load a “shape file” that has the outlet for the watershed.
6. Determining watershed area using channel threshold value.
 - Set the channel formation threshold value to something like 100 or 1000 or 5000 depending on the size of your watershed and goals of your analysis. There is no standard threshold value.
7. *Overlay Soil map.*
 - In this model, the concept of surface soil indicates the depth (range) where pores exist to temporarily store intermediate runoff. In the DWAT, infiltration and evapotranspiration into/from soil are analyzed based on the physical characteristics of soil, and thus surface soil parameters should be established. The physical characteristics of soil (including soil depth, saturated hydraulic conductivity, horizontal hydraulic conductivity, saturated moisture contents, residual moisture contents and Mualem's n) are used in this model. The information on the surface soil depths and parameters is used after being classified by soil texture based on the 1:25,000 precise soil map.
8. *Overlay Land use map*
 - Input data for land use conditions includes ground surface slopes, impervious area ratios and depression storage. The information on topological parameters is based on land use map from the National Geographic Information System (NGIS).

First go to Main Menu and select GIS Preprocessor.





DEM: A browser will be displayed allowing the user to select the DEM grid (Raster file: hdr.adf).

This file format (*.adf) is the internal binary format for Arc/GIS Grid, and takes the form of a coverage level directory in an Arc/GIS database. To open the coverage select the coverage directory, or hdr.adf from within it.



Click Open to proceed. When this step is complete, DEM and flow accumulation theme is added to the GIS Preprocessor view.






OUTLET: It allows users to add an outlet point.


Once you have zoomed in, go to the Select outlet browser. Make sure to select which folder to use whichever one has the newly created shape file for the outlet point. Click “Add point”, directly user placed from add point using left-clicking on a stream pixel.

If you are off the stream channel by so much as one pixel you will not delineate the correct drainage area. Your outlet point must be in a flow channel pixel.




Click OK to proceed. You are ready to delineate watershed area.

BASIN: It allows you to delineate watershed area using channel threshold value.




Click OK to proceed. You have delineated a watershed.




SOIL: It allows you to overlay soil type theme to the watershed boundaries.

DWAT require land use and soil data to determine the area and the hydrologic parameters of each land-soil category simulated within each sub-watershed. If the soil and land use is defined in the same projection as the DEM, select shape file (*.shp) in file browser. If soil map is not projected as the DEM, This will stop map processing.


When this step is complete, a dialog box will pop up listing database files from which soil type can be selected. User need to define DWAT soil type associated with soil type theme categories. Select the attribute field containing the codes/category values to be reclassified: SO_TYPE.




Click OK to proceed.




LANDUSE: It allows you to overlay land use theme to the watershed boundaries. Select land use theme (*.shp).




When this step is complete, a dialog box will pop up listing database files from which soil type can be selected. Select the attribute field containing the codes/category values to be reclassified: UCB.



Click OK to proceed. Land use theme is added to the watershed boundaries.




RUN: It allows you to determine the area and the hydrologic parameters of each land-soil category simulated within each sub-watershed. When this step is complete, land use attributes box will appear stating that the land use theme has been processed to the watershed boundaries. The attributes box also remind the user to edit a look-up table or manually define the land use classes for the theme.




You can manually assign a land use NAME and TYPE.


- To manually assign land use NAME, double-click in the NAME fields.



- To manually assign land use TYPE (Pervious, Impervious and Plant), highlight the desired database item by clicking on it.




Click OK to proceed. This will return you to the definition of soil attributes box.




The attributes box also remind the user to edit a look-up table or manually define the soil classes for the theme.

You can manually assign a soil NAME, TYPE and Properties.


- To manually assign soil NAME, double-click in the NAME fields.




- To manually assign soil TYPE, highlight the desired database item by clicking on it.




- To manually assign soil Properties, double-click in each fields.




Once the joining attribute codes have been assigned to all map categories, the file browser will be appeared. It allows the current file to save in text file format (attribute information and data of the watershed).



Click SAVE to proceed. Hydrologic model is created.



Click OK to proceed. When you close the GIS Preprocessor window, Delineated watershed is appear.




2.1.5 Model

Table: The results for hydrologic component at each source node can be displayed at table


The Series window displays a table of hydrologic data for Catchment 1. The table has the following columns: Date, Inflow[S@], Rainfall[mm], Actual, Potential, Flow Surface[mm], Flow Inter[mm], Flow Groundwater, Flow Total[mm], Infiltrate[mm], Recharge[mm], and Groundwater. The data is shown for a period from 2002/01/01 00:00 to 2002/07/26 00:00, with a count of 2191. The table is sorted by date, and the row for 03/07/18 00 is highlighted.

Date	Inflow[S@]	Rainfall[mm]	Actual	Potential	Flow Surface[mm]	Flow Inter[mm]	Flow Groundwater	Flow Total[mm]	Infiltrate[mm]	Recharge[mm]	Groundwater
562 03/07/16 00	0.00	0.00	0.00	6.39	0.00	0.00	1.09	1.09	0.00	0.00	0.00
563 03/07/17 00	0.00	0.10	0.00	4.52	0.00	0.00	1.05	1.05	0.07	0.00	0.00
564 03/07/18 00	0.00	48.50	0.01	2.37	6.04	22.04	1.01	29.10	32.49	10.52	0.00
565 03/07/19 00	0.00	13.50	0.26	4.33	1.49	7.89	1.37	10.76	9.05	1.15	0.00
566 03/07/20 00	0.00	6.50	0.24	2.69	0.60	0.00	1.36	1.96	4.36	0.00	0.00
567 03/07/21 00	0.00	0.10	1.78	3.24	0.00	0.00	1.31	1.31	0.07	0.00	0.00
568 03/07/22 00	0.00	121.50	0.01	2.32	15.53	73.79	1.26	90.59	81.40	10.52	0.00
569 03/07/23 00	0.00	4.50	0.24	2.68	0.34	0.00	1.61	1.96	3.02	0.00	0.00
570 03/07/24 00	0.00	1.00	0.26	4.24	0.00	0.00	1.55	1.55	0.67	0.00	0.00
571 03/07/25 00	0.00	9.50	0.13	3.83	0.97	7.64	1.49	10.10	6.37	2.41	0.00
572 03/07/26 00	0.00	0.00	0.26	4.86	0.00	0.00	1.53	1.53	0.00	0.00	0.00


Chart: Graphs of the simulation results after running the model will appear on screen.



Model Setup: It allows users to set up environments for running the model (e.g. simulation time and period)



Run : It allows users to execute model simulation



2.1.6 Help

Manual: It is a view menu for the DWAT user manual


Support: It allows users to link to the DWAT's website

About CAT: It is a menu to identify the copyright and version information of the DWAT




2.2 Icon

The user interface of the DWAT basically includes 10 icons. There are: Three basic nodes (i.e. Catchment, Reservoir, Wetland); and four functions for catchment configurations (i.e. Links, Junctions, Recycle, Import and Outlets to connect between nodes). In addition, Select and Climate icons are included to check attributes.



2.3 Property View

The Property View displays the attribute information of each node, link and junction. That is, an attribute information screen automatically appears on the left when a node, link or junction is individually selected on the main screen. Information on parameter values can be identified and corrected.



Chapter 3: Model Input Data

The DWAT requires various input data to reflect watershed characteristics, such as topology, geological features, hydrologic and hydraulic features, artificial systems for water use and drainage, in the analysis of water cycle.

In the analysis, the DWAT uses physical parameters based on physiographic factors, soil and groundwater as shown in Table 3.1. Physical parameter values can be established using land use data, soil diagrams and river data, etc. Table 3.1 ~ Table 3.3 contain a list of input data at source nodes (i.e. urban, forest, paddy and water cycle improving facilities) and links. In this chapter, the processes to create, extract and process these input data are explained in detail.

<Table 3.1> Model parameter (Catchment nodes)

Division	Input variable	Description of variable	Unit
Subject watershed	Area	Area	km ²
Meteorological condition	Latitude, Elevation, Height	the location, elevation and height of the observatory	m
	Climate data	rainfall, wind velocity, sunshine hours, lowest/highest temperatures, relative humidity	-
Ground surface condition	Slope	catchment average slope	-
	Aratio_imp	impervious area ratio	%
	Aratio_per	pervious area ratio	%
	Aratio_per_plant	Vegetation area ration in pervious zone	%
	DepC_imp	depression capacity in impervious zone	mm
	DepC_per	depression capacity in pervious zone	mm
Surface soil	theta_per	current soil moisture content	-
	soil_th_per	soil thickness	m
	s_per	Saturated soil moisture content	-
	r_per	residual soil moisture content	-
	FC_per	SMC at field capacity	-
	W_per	SMC at wilting point	-
	ks_per	saturated hydraulic conductivity	mm/s
	ksi_per	Saturated horizontal hydraulic conductivity	mm/s
	Mualem	Index for Mualem Eq.	-
	PSI	wetting front soil suction head	mm
	f _o	maximum or initial value of infiltration capacity into soil	mm/hr
	f _c	maximum or ultimate value of infiltration capacity into soil	mm/hr
	k	decay coefficient	hr ⁻¹
River	rivE	riverbed elevation	m
	Area_riv	area of riverbed	km ²
	riv_th	thickness of riverbed	m
	ku_riv	riverbed material permeability coefficient	mm/s
Groundwater aquifer	gwE	current groundwater level	m
	aqf_S	storage coefficient of aquifer	-
	aqf_Top	top elevation of aquifer	m
	aqf_Bot	bottom elevation of aquifer	m

	aquifer slope	average slope of aquifer	-
	node length	average node length	m
	conj. length	conjugated length between nodes	m
	Kgw	saturated hydraulic conductivity of aquifer	mm/s
	GW_pump_rate	groundwater pumping rate	m ³ /day
	leakage_rate	leakage rate of water supply networks	-

<Table 3.2> Model parameters (Other node)

Division	Input variable	Description of variable	Unit
Reservoir (online/offline)	vol_init	initial storage	m ³
	vol_eff	effective storage	m ³
	intake_vol	intake volume	m ³ /day
	Kgw	saturated hydraulic conductivity of aquifer	mm/s
	spill_ht	Height of spillway	m
	spill_length	Length of spillway	m
	spill_coef	overflow coefficient of spillway	-
	pipe_ht	Height of outlet pipe	m
	pipe_area	Area of outlet pipe	m ²
	pipe_coef	runoff coefficient of outlet pipe	-
	offline_max	Maximum inflow into offline pond	m ³ /sec
	offline_ratio	Control ratio for offline inflow	-
	offline_out	downstream outflow from offline pond	m ³ /sec
	H-V-A	stage-storage-area relationship	m-m ³ -m ²
Wetland	vol_init	initial storage	m ³
	vol_max	maximum storage	m ³
	flood_bypass	High flow bypass during flood	m ³ /sec
	Kgw	saturated hydraulic conductivity of aquifer	mm/s
	pipe_ht	Height of outlet pipe	m
	pipe_area	Area of outlet pipe	m ²
	pipe_coef	runoff coefficient of outlet pipe	-
		H-V-A	stage-storage-area relationship
Recycle	rec_intake	Total intake volume	m ³ /day
	rec_cond	Restriction for intake rate according to streamflow	%

external water supply	import_water	Constant volume or time series data of imported from outside	m ³ /day
	Leakage	leakage rate	%


<Table 3.3> Model parameter (link, channel routing)

Division		Input variable	Description of variable	Unit
Channel routing	Muskingum	DT	time step for calculation	unit time
		X	routing factor (0.0 ~ 0.5)	-
		K	wave travel time	hr
	Muskingum Cunge	Channel length	length of channel	m
		Channel slope	bed slope of channel	-
		Manning N	Manning roughness coefficient	-
		Top width	top width of channel	m
	Kinematic wave	Manning N	Manning roughness coefficient	-
		Channel slope	bed slope of channel	-
		Channel length	length of channel	m
		Bottom width	bottom width of channel	m
Top width		top width of channel	m	
Channel depth		channel depth	m	

3.1 Subject Catchment


The range of water cycle assessment primarily consists of watershed systems, including stream network. In the stage of composing a watershed system, catchment information is required and information on water level stations is needed to compare simulation results to observed data. The user can import images of watershed systems including catchment information as the background. It allows users to configure links and source nodes easily.

3.1.1 Background Image



(교체)

Load: It allows users to insert background images




(교체)

Adjust: It allows users to adjust the location and size of imported background images

Delete: It allows users to delete background images


When a background image has been loaded, a screen as shown below is created.



3.2 Climate


The DWAT requires the meteorological time series such as the highest/lowest temperatures, wind velocities, sunshine hours, humidity, etc. the model was designed to enable loading not only text files but also Microsoft Excel files. When inputting meteorological data in Excel or text files, the model has also been designed to enable users to freely load time series data defined by the users without standardized file formats. It facilitates the easy usage and management of the program. In addition, the user can not only choose weather stations but also can allocate weighted values from the Thissen networks at each node. The location of each weather station, the height from the ground of each observing device and the latitudes should also be collected. They are necessary to calculate potential evapotranspiration by the Penman-Monteith method.

3.2.1 Climate Data Import



(교체)

Create series: It allows users to create Excel (*.xls), text (*.txt), and DBF (*.dbf) formats of meteorological data into the DWAT input data file (*.dat) format. The following window will pop up.




(교체)

Time step: time step for climate data (min, hour, day month, year)


Period: time of start and finish

Field: specify the type of field for input (to calculate the evapotranspiration, temperature, wind, humidity)

and sunshine hours selected. After select the field name and click the Add), the user can prepare his/her own data with format of *.xls or *.txt and Copy & Paste can be carried on.



(교체)




(교체)

Series file D:\CAT-U_jang\penman_0202\climate_0228.dat : Click and enter the saving directory and file name.


File header: : Enter the file description.

Save: The file will be saved as DWAT time series input data by pressing the ‘Save’ button. When the saving has been completed, press the ‘Confirm’ button.




3.2.2 Climate Data Checking

To check whether data have been properly saved or not, the following process should be performed:




Series: It allows users to display all data files created in the DWAT in the screen. View > Series gives the following window. Pressing this button to display meteorological data previously saved, and then pressing this button to load the time series data in the spread sheet of the window as shown in


the following figure.




The following figure appears on the upper part of the 'Series View' window. It shows information of the data file: the time interval (one hour), the number of data rows (17,544) and the data start time (2000/01/01 00:00).



C This is a function to modify the time interval for input data. Once it has been selected, the current time interval appears. The process is: change the time interval in the 'NEW' tab; select whether to show the sum, average, maximum or minimum in the 'Method' tab; and then press 'OK'. The changed time interval will be displayed.





Export: If meteorological data imported by the DWAT have been checked, these data may be exported in text file format (*.txt). These text format data may be opened and checked in general text editors.




Save In addition, meteorological data imported into the ‘Series View’ may be revised and the revised data may be saved under another name.

3.2.3 Climate Node Entry


 After completing the processes of setting the catchment system and importing meteorological data, the user will reach the stage to enter meteorological nodes. As mentioned earlier, the DWAT is a node-link model and the user can select icons (e.g. link, source and junction) with a mouse to easily configure

catchment information. A climate node will be created by clicking the left mouse button on the appropriate position in the 'Main Interface' after selecting the Weather icon  in the menu. The same process is required to configure multiple weather stations.




When meteorological data is used in the DWAT, the user not only can choose climate stations having meteorological data but also may allocate weighted values from the Thissen network at each node. Although meteorological data had to be separately established to use the Thissen network, data were fixed as meteorological data to be used for one node in existing urban water cycle models. In the DWAT, weighted values as shown in the following Figure were configured for usage.^[H1]


To back to meteorological node inputs, the user should enter weather station information and conditions for simulations. After left-clicking on a meteorological node, the following window will appear on 'Property View'.



Property: This is a menu to import meteorological data and enter weather station information. .



Climate station names may be modified in the 'Name' column and a brief description is to be entered into the 'Descript' column. After that, press a button under 'Climate' to import meteorological data.



Calculate: By selecting ‘True’, parameters to calculate Penpan-Monteith potential evapotranspiration can be brought from meteorological data. If ‘false’ is selected, the program will use the potential evapotranspiration entered by users.

Latitude, Elevation and Height: This a dialog box to enter the location of the climate station (latitude, elevation and height). This function is used when the ‘True’ option has been selected.

When all information of the meteorological nodes have been defined, press the ‘OK’ button.


Table: This is a menu to identify rainfall and calculated evapotranspiration in a table. This function may be used once the model has been executed. That is, this menu is used to view results after running the model. Meteorological data can be identified at the View > Series menu.




Chart: This is a menu to view graphs from the model runs. This function is provided in not only a meteorological node but also all links, nodes and junctions. No matter which of them is selected, an identical window will appear (i.e. no matter which source node, link or junction is selected, graphs at all points can be identified). This menu will be explained in the 'Result Analysis' chapter in detail.



Following graph shows the result of Potential evapotranspiration (ET_p) and actual evapotranspiration at source node.



DWAT can use the rainfall gauges in network. The Thiessen weight coefficient can be specified to each source node. Also it can specify different stations for climate data and stations for rainfall data considering the climate measuring stations are rare compare to rainfall measurement. The maximum gauging stations to apply climate and rainfall are five. .



ET method: It allows users to select actual evapotranspiration calculation methods

Method	Monthly Coefficient
Jan	Monthly Coefficient
Feb	Leaf Area Index
Mar	FAO56
Apr	0.7
May	0.7
Jun	0.7
Jul	0.7
Aug	0.7
Sep	0.7
Oct	0.7
Nov	0.7
Dec	0.7


Monthly Coefficient: A method to calculate actual evapotranspiration by multiplying the potential evapotranspiration with monthly coefficients.

Leaf Area Index: A method to calculate actual evapotranspiration considering monthly leaf area indexes (LAI, Leaf Area Index) and soil moisture contents (the same method used in the SWAT, Soil and Water Assessment Tool)

FAO 56: The actual evapotranspiration is calculated by the Penman-Monteith method in FAO56 using climate data (Max. & Min. air temperature, sunshine hours, humidity and wind speed).

Climate	
Evaporate	
Method	Monthly Coefficient
Jan	0.7
Feb	0.7
Mar	0.7
Apr	0.7
May	0.7
Jun	0.7
Jul	0.7
Aug	0.7
Sep	0.7
Oct	0.7
Nov	0.7
Dec	0.7

The above figure shows how to enter monthly coefficients. Monthly evapotranspiration correction coefficients and monthly leaf area indexes (LAI) are entered in the monthly method and the AETSWAT, respectively. The types of vegetation used in the model are divided into four groups: forests, grasslands, urban trees and crops (Jia, Y., 2002). The leaf area indexes are values from a previous study (A study on the development of watershed diagnosis methods for establishing healthy water cycle systems, 2005). The following figure shows the leaf area indexes (LAI) applied to the model.



3.3 Ground Surface

Once entries of the meteorological nodes have been completed, information on the source nodes, links and junctions configured about sub-catchments is to be entered one by one. Input data for ground surface conditions includes ground surface slopes, impervious area ratios and depression storage as shown in Table 3.1. In general, depression storage in impervious zones is understood as 2mm. Examples of impervious area ratios by land use are shown in the Table 3.4.


<Table 3.4> Classification of land cover


Classification	Class 1	Class 2	Ratio Impervious area * (%)
1	Urban	residential	65
2		industrial	72
3		commercial	85
4		recreation	50
5		road	100
6		public	60
7	Agriculture	paddy	-
8		upland	-
9		Green house	-
10		orchid	-
11		Etc.	-
12	Forest	decidious	-
13		coniferous	-
14		mixed	-
15	Grass	natural	-
16		golf course	-
17		Etc.	-
18	Wetland	inland	-
19		coastal	-
20	Bare soil	mines	-
21		etc	-
22	Water	inland	-
23		sea	-

* Ratio of impervious area (Guideline for river planning, KWRA, 2009)

In this chapter, entry processes for the basic ground surface condition of the Catchment node will be explained in detail.

3.3.1 Catchment Node Entry

 Catchment node will be located by placing each of the Catchment node icons at an appropriate position on the Main Interface and left-clicking the mouse after selecting each node icon.



3.3.2 Parameter Entry

In the following Figure, the 'Property View' will show the information on the catchment node.

The 'Property View' is used to enter or revise all catchment node data (ground surface, soil, groundwater aquifer, etc). Basic ground surface conditions are to be entered under the node.

Property	
Property	
Catchment node	
Name	Catchment 1
Descript	
Area	2.7117
Impervious	13
Pervious	87
Plant ratio	21
Slope	0.05
depC_per	5
depC_imp	2

Name: This indicates source node (sub-catchment) names.

Descript: Information of a source node (sub-catchment) may be entered.


Area: source node (sub-catchment) area.

Slope: watersheds' average slope.

Impervious: impervious area ratio.

Pervious: pervious area ratio.

Plant ratio: vegetation area ratio in pervious zone (This parameter is an evapotranspiration-related variable that is divided into four types, including forests, grasslands, urban trees and crops, and the range of the variable and these values are shown in the following figure (Jia, Y., 2002)).



DepC_imp: depression capacity in impervious zone (generally 2 mm)

DepC_per: depression capacity in pervious zone

3.4 Soil

In this model, the concept of surface soil indicates the depth (range) where pores exist to temporarily store intermediate runoff. In the DWAT, infiltration and evapotranspiration into/from soil are analyzed based on the physical characteristics of soil, and thus surface soil parameters should be established. The physical characteristics of soil (including soil depth, saturated hydraulic conductivity, horizontal hydraulic conductivity, saturated moisture contents, residual moisture contents and Mualem's n) are used. The information on the surface soil depths and parameters is used after being classified by soil texture based on the 1:25,000 precise soil map. The following table is utilized based on the study (A study on the development of watershed diagnosis methods for establishing healthy water cycle systems, 2005). In Table 3.5, the horizontal hydraulic conductivity is determined by giving 10 times the values of the saturated hydraulic conductivity.


<Table 3.5> Surface soil input parameters by soil texture

Soil texture	saturated moisture content ratio s_per	residual moisture content ratio r_per	SMC, field capacity FC_per	SMC, wilting point W_per	saturated hydraulic conductivity Ks_per (mm/s)	Horizontal hydraulic conductivity Ksi_per (mm/s)	Mualem's n
Sand	0.437	0.020	0.091	0.033	6.5E-02	6.5E-01	3.37
Loamy Sand	0.437	0.035	0.125	0.055	1.7E-02	1.7E-01	3.64
Sandy Loam	0.453	0.041	0.207	0.095	6.1E-03	6.1E-02	3.91
Loam	0.463	0.027	0.27	0.117	3.7E-03	3.7E-02	4.17
Silty Loam	0.501	0.015	0.3	0.133	1.9E-03	1.9E-02	4.20
Sandy Clay Loam	0.398	0.068	0.33	0.148	8.3E-04	8.3E-03	4.23
Clay Loam	0.464	0.075	0.255	0.197	5.6E-04	5.6E-03	4.26
Silty Clay Loam	0.471	0.040	0.318	0.208	5.6E-04	5.6E-03	4.29
Sandy Clay	0.430	0.109	0.366	0.239	3.3E-04	3.3E-03	4.32
Silty Clay	0.479	0.056	0.339	0.250	2.8E-04	2.8E-03	4.35
Clay	0.475	0.090	0.384	0.272	1.7E-04	1.7E-03	4.38

* Rawls & Brakensiek Soil parameter estimates (1985).

3.4.1 Parameter entry

The 'Property' window is opened by left-clicking on each source node.



Soil	
theta_per	0.25
soil thick	47.6402
Saturate	0.455007
Residual	0.0664587
Field capacity	0.285145
Wilting point	0.189706
ks	0.00181713
ksi	0.0181713
Mualem	7
Inf method	Rainfall Excess
PSI	13.9638
k	4.14
Fc	9.5
Fo	80.7998

theta per: This is the current moisture content of the soil. 0.25 is a default value and this value may change at each time step. It is a computed value between saturated moisture content ratios and residual moisture content ratios.

soil thick: This is the soil thickness generally in a range of 1 - 5.

Saturate: This is the saturated soil moisture content ratio in a range of 0.4 - 0.6 (refer to Table 3.5).

Residual: This is the residual soil moisture content ratio in a range of 0.02 - 0.2 (refer to Table 3.5).

Field capacity: This is the soil moisture content at field capacity in a range of 0.1 - 0.5 (refer to Table 3.5).

Wilting point: This is the soil moisture content at wilting point in a range of 0.03 - 0.3 (refer to Table 3.5).

ks: This is the saturated hydraulic conductivity in a range of 0.1×10^{-4} - 0.7×10^{-1} (refer to Table 3.5).

ksi: This is the horizontal hydraulic conductivity in a range of 0.1×10^{-3} - 0.7 (refer to Table 3.5).

Mualem: When calculating vertical and horizontal infiltration, this model uses the Mualem equation, which utilizes unsaturated hydraulic conductivity. This shows the n (index) value of the Mualem equation, which is the input parameter. This value is in a range of 3 - 5 (refer to Table 3.5).

Inf method : Selection for infiltration method, Rainfall Excess, Green & Ampt, Horton method are provided.

Soil	
theta_per	0.25
soil thick	47.6402
Saturate	0.455007
Residual	0.0664587
Field capacity	0.285145
Wilting point	0.189706
ks	0.00181713
ksi	0.0181713
Mualem	7
Inf method	Rainfall Excess
PSI	Rainfall Excess
k	Green&Ampt
Fc	Horton
Fo	80.7998

PSI: Capillary suction head for Green & Ampt method. Table 3.6 shows the typical values of PSI

<Table 3.6> Typical value of PSI

Soil type	PSI (mm)
Sand	49.5
Loamy Sand	61.3
Sandy Loam	110.1
Loam	88.9
Silt	130.7
Silty Loam	166.8
Sandy Clay Loam	218.5
Clay Loam	208.8
Silty Clay Loam	273.0
Sandy Clay	239.0
Silty Clay	292.2
Clay	316.3

* Rawls & Brakensiek Soil parameter estimates (1985)

k : decay constant for soil used by Horton method.

fc : Minimum infiltration capacity for Horton method. See Table 3.6

fo : Maximum infiltration capacity by Horton method. It affected by the type of soil, initial soil moisture and the surface condition. See Table 3.7

<Table 3.6> Typical minimum infiltration capacity (fc)

Soil drainage Classes	Minimum Infiltration (fc) (mm/hr)
A (Excessively drained)	11.43 ~ 7.62
B (Well drained)	7.62 ~ 3.81
C (Poorly drained)	3.81 ~ 1.27
D (Very Poorly drained)	1.27 ~ 0.0

* XP-SWMM User's Manual (2007)


<Table 3.7> Typical maximum infiltration capacity (fo)

Soil type	Maximum Infiltration (fo) (mm/hr)
A. Dry soils (with little or no vegetation)	
Sandy soil	127.0
Loam soil	76.2
Clay soil	25.4
B. DRY soils (with dense vegetation)	
Sandy soil	254.0
Loam soil	152.4
Clay soil	50.8
C. MOIST soils	
Soils which have drained but not dried out	Sandy soil 84.7
Soils close to saturation	Loam soil Choose value close to minimum infiltration rate
Soils which have partially dried out	Clay soil 33.9

* XP-SWMM User's Manual (2007)

3.5 River

Since the parameters related to channels in the DWAT are closely related with groundwater aquifers, the model was designed to enter the parameters in the 'Property View' window. It is shown in the following figure. Channel specifications can be entered using the existing report or field survey. In this section, channel specification related variables will be explained and groundwater aquifer input parameters will be addressed in the next section.



Aquifer	
gwE	35
rivE	34
Bed thick	1
ku_riv	0.004
Area	0.03
aqf_S	0.1
Top	36
Bottom	26
Pumping	0
Leakage	0.15

rivE: riverbed elevation

Bed thick: riverbed material thickness (1.0 is a default value and this value is in a range of 0.1 - 1.0 depending on river elevation)

ku_riv: hydraulic conductivity of riverbed material (the range of 1.0×10^{-4} - 1.0×10^{-6} is generally used)


Area: riverbed area

3.6 Groundwater Aquifer

In the DWAT, groundwater and river runoff are simulated using the relationship between groundwater and river levels. That is, if the groundwater level is higher than the river level, water will flow into the river depending on soil hydraulic conductivity. Conversely, if the river level is higher than the groundwater level, water will percolate into the aquifer. The model was designed to consider groundwater pumping and leakage from water supply networks. The leakage is simulated to flow into soil layer. In addition, moisture content movements between aquifers are considered. That is, level changes in

groundwater by moisture content movements between aquifers in each sub-catchment can be analyzed. As shown in the following figure, parameters related to aquifer specification may be entered under the ‘Aquifer’ tab while comparing with channel specifications in order to determine the mutual relationship between groundwater and river levels. Each parameter will be reviewed in detail in the following section.

3.6.1 Aquifer Specification Entry



Aquifer	
gwE	35
rivE	34
Bed thick	1
ku_riv	0.004
Area	0.03
aqf_S	0.1
Top	36
Bottom	26
Pumping	0
Leackage	0.15

gwE: This indicates the initial groundwater level. This value will vary through the year if there is no initial groundwater level in each modeling period. Thus it is necessary to start the calculation from approximately one year before the analysis period in order to minimize the effect of uncertainty from the initial groundwater values during simulation.

aqf S: This indicates storage coefficient of aquifer. If there are records, a value in a range of 1.0×10^{-1} - 1.0×10^{-2} is recommended.

Top: The elevation of aquifer shall be determined by deducting the surface soil thickness from the ground surface elevation.


Bottom: The bottom elevation of aquifer shall be determined by referring to existing examinations. When there are no field surveyed data, this value is generally assumed to be 20m ~ 30m below the top elevation of the aquifer. For existing records, groundwater survey reports for sub-catchment or field data can be used.

Pumping: This indicates the groundwater pumping rate


leackage: This indicates the leakage rate from water supply networks. 15% is generally recommended and 0.15 is a default value.

3.6.2 Groundwater Movement Parameter Entry

Parameters related to groundwater movement between adjacent sub-catchments are entered through a separated 'Property View'. It is shown in the figure below.



Connect: This is a window for selecting adjacent sub-catchment nodes to consider groundwater movement.



Use slope: This indicates groundwater hydraulic gradient. It can be obtained by calculation when the groundwater level is known for a catchment. However, if there is no information, it is generally recommended to use values smaller than ground surface slope.

Node length: This indicates a average distance between adjacent sub-catchments

Conj. length: This indicates a conjuncted length between adjacent sub-catchments

Kgw: This indicates hydraulic conductivity of aquifer. A value in a range of $1.0 \times 10^{-4} \sim 1.0 \times 10^{-6}$ is recommended.


3.7 Reservoir

Ponds can be divided into two types: online and offline reservoirs. For offline reservoirs, the ratio of maximum inflows from the stream to the offline reservoirs to the mainstream discharge are predefined. It is used to calculate inflows into the offline reservoirs. Then, the mainstream discharge that will be a condition for discharge from the offline reservoirs to the mainstream is to be established in order to determine the outflow to downstream. Offline reservoirs are simulated to be emptied after a flood. In the case of online reservoirs, evaporation from water surface is considered. The reservoir storage, water level and discharge are calculated using the initial storage, effective storage, intake (here, water is taken only when the storage is at least 20% of the effective storage volume), the specifications of spillways and discharge outlet in the reservoir.

Storage and water levels for both of the types are renewed by inflows based on the relationships of stage-storage-area.



The reservoir nodes are entered by selecting the ‘Reservoir’ icon and placing it in an appropriate position in the ‘Main Interface’ with clicking the left button on a mouse.



If the pond node is right-clicked, a window to set the parameters related to ponds will appear.

Pond node	
Name	Reservoir 1
Descript	

Climate	
Rainfall	
Climate	

Base	
Type	Online
vol_init	1e+006
vol_eff	1e+006
Kgw	0.0005
Recharge to	

Pipe	
pipe_ht	5
pipe_area	1
pipe_coef	0.5

Spillway	
spill_ht	15
spill_length	30
spill_coef	0.8

Offline	
offline_max	0.5
offline_ratio	0.5
offline_out	1

Intake	
Type	Constant
Supply to	None
Intake	10000
Series file	
Table	
Field	

WL-Volume-Area Relationship					
	1	2	3	4	5
WL(m)					
VOL(m3)					
AREA(m2)					

Name: This indicates reservoir name.

Descript: Information of the reservoir may be entered.

Rainfall: rainfall station for the rainfall on the surface of reservoir. It uses the selected adjacent rainfall station.

Climate: climate station for evapotranspiration from the surface of reservoir. It uses the selected adjacent weather station.


Type (Base tab): This is to select the type of the reservoir (online/offline).

vol_init: Initial storage

vol_eff: Effective storage

Kgw: This indicates reservoir's bottom saturated hydraulic conductivity. This parameter is used to calculate the amount of loss in the bottom of reservoir. The value is in a range of 1.0×10^{-3} - 1.0×10^{-5} .

Recharge to: The loss from the bed of reservoir can be calculated by hydraulic conductivity (Kgw). If “Recharge to” is selected, the recharged water can be transferred to catchment node to recharge groundwater.



Base	
Type	Online
vol_init	1e+006
vol_eff	1e+006
Kgw	0.0005
Recharge to	
Pipe	Catchment 1
pipe_ht	Catchment 2
pipe_area	Catchment 9
pipe_coef	Catchment 7
Spillway	Catchment 11
spill_ht	Catchment 5
spill_length	Catchment 4
spill_coef	Catchment 10
Offline	Catchment 8
	Catchment 6

pipe ht: Pond's outlet height

pipe area: Pond's outlet area

pipe_coef: Pond's outlet runoff coefficients in a range of 0.5 - 1.0

spill ht: Height of spillway

spill length: Length of spillway

spill_coef: Overflow coefficient of spillway in a range of 0.3 - 1.7

Type (Intake tab): This is to select the type of the intake type (Constant/Time series).

Intake	
Type	Constant
Supply to	Constant
Intake	Series
Series file	
Table	
Field	

Supply to: The intake from the reservoir can be transferred to selected node. To use this function the Recycle node must be located at the downstream of the reservoir node..

intake: This is intake volume from the reservoir. Water is taken only when the storage is at least 20% of the effective storage

The online reservoir input parameters are described above. The following description is for offline reservoir input parameters.

Offline	
offline_max	0.5
offline_ratio	0.5
offline_out	1

offline_max: This indicates maximum inflow into offline reservoirs. The streamflow discharge that does not flow into offline reservoirs is added to downstream links.

offline_ratio: This indicates ratio for inflow into offline reservoirs to the streamflow discharge.

offline_out: This indicates the stream discharge as a condition for discharge into the river.

WL-Volume-Area Relationship					
	1	2	3	4	5
WL(m)					
VOL(m3)					
AREA(m2)					


As shown in the above Figure, the amount of storage and the storage water level relative to the amount of inflows are based on the relationships among water levels-storage amounts-areas.

3.8 Wetland


The storage of wetlands was assumed to be the initial condition. It was also assumed that the excess flow is to be sent to the downstream node when inflow is larger than the high flow bypass during flood. After calculating the volume of the remaining inflow, all of the volume will be overflowed when the volume is larger than the maximum storage. The module was designed to calculate water level, area, evaporation from the water surface and discharge through the outlet based on the final remaining storage volume.



The wetlands node is entered by selecting the icon shown in the following figure, placing it on an appropriate position in the 'Main Interface' with clicking the left button on a mouse.



If the wetland node is left-clicked, a window to set the parameters related to wetlands will appear.



Name: This indicates wetland name.

Descript: Information of wetland overview may be entered.

Rainfall: rainfall station for the rainfall on the surface of wetland. It uses the selected adjacent rainfall station.

Climate: weather station for evapotranspiration from the surface of wetland. It uses the selected adjacent weather station.

Init Volume: Initial storage

Maximum storage: Maximum storage

Flood bypass: High flow bypass during flood

Kgw: This indicates pond's bottom saturated hydraulic conductivity. This parameter is used to calculate the amount of loss in the bottom of ponds. The value is in a range of 1.0×10^{-3} - 1.0×10^{-5} .

Recharge to: The loss from the bed of wetland can be calculated by hydraulic conductivity (Kgw). If “Recharge to” is selected, the recharged water can be transferred to catchment node to recharge groundwater.

Base	
Init volume	10000
Maximum storage	100000
Flood bypass	1
Kgw	0.0005
Recharge to	Catchment 9
Pipe	
Pipe height	Catchment 2
Pipe area	Catchment 9
Pipe coefficient	Catchment 7
	Catchment 3
	Catchment 11
	Catchment 5
	Catchment 4
	Catchment 10
	Catchment 8
	Catchment 6

pipe height: Height of outlet pipe

pipe area: Area of outlet pipe

pipe coefficient: Runoff coefficient of outlet pipe in a range of 0.5 ~ 1.0

WL-Volume-Area Relationship					
	1	2	3	4	5
WL(m)					
VOL(m3)					
AREA(m2)					

Evaporation from water surfaces and the discharge in the wetland are calculated through a renewal of storage and water level of wetlands based on the stage-storage-area relationships. It is similar to the calculation process of reservoirs.

3.9 Recycle


In order to review the processes for designing recycle, the inflow is calculated and the daily used intake volume is then distributed to individual nodes. Water intake is restricted by defining intake restriction for intake rate determined by streamflow discharge rate.

That is, if the value obtained by considering the inlet inflow amount and the intake restriction ratios is larger than the intake amount, the recycling inflow amount will be the same as the intake amount and the


amount of runoff to the toe will become the value obtained by deducting the intake amount from the inlet inflow amount. If the inlet inflow amount, considering the intake restriction ratios, is lesser than the intake amount, the recycling inflow amount will be the same as the inlet inflow amount considering the intake restriction ratios. The amount of runoff to the toe is the value obtained by deducting the intake amount from the inlet inflow amount.



The Recycle node will be entered by selecting the icon shown in the following figure, placing it on an appropriate position in the 'Main Interface' with clicking the left button on a mouse.



If the Recycle node is right-clicked, a window to set the parameters related to the Recycle will appear.



Name: This indicates Recycle node name.

Descript: Information of Recycle node may be entered.

Intake: Total intake volume


rec_cond: Restriction for intake rate according to mainstream flow rate. The DWAT has a function to send the determined discharge to many catchment nodes (maximum five nodes) using Recycle.

3.10 Import


Parameters related to the water use from outside of catchments are used to design the Import function. A constant amount on a daily basis is used, and time series data for water supply data can be loaded.



The Import node may be entered by selecting the icon shown in the following figure, placing it on an appropriate position with clicking the left button on a mouse.



If the Import node is left-clicked, a window to set the parameters related to the Import will appear.



Name: This indicates a node name

Descript: Information of the node may be entered.

Type: This is to select the type of data to be imported: ‘constant’ for a constant daily amount; ‘series data’ for time series data for water supply.


Import water: This indicates imported water supply amounts. It is activated when the constant type is selected.

Leakage : Leakage from pipe network can be considered (The leaked water added to soil moisture in pervious area)


Series file: This is to load the time series data for water supply. This is activated when the series data type is selected. A screen to choose the file appears and the data can be loaded by pressing ‘Time Series Data > Open’. The data file should be created using the ‘File > Create series’ menu as with the process to import meteorological data described in Section 3.2 (The ‘Type’ should be set as ‘User defined’).

3.11 Channel Routing (Link)

In the DWAT, the channel routing is a process to convert inflow hydrologic curves into runoff hydrologic curves in channel sections using the Muskingum, Muskingum-Cunge and Kinematic wave methods. In this section, the selections of methods of inputting data and routing methods in the Link are described in detail.



If the Link that connects nodes together is left-clicked, a window to set the parameters for the Link will appear.




Name: This indicates a link name.

Descript: Information of a link may be entered.

Routing Method: This is to set channel routing methods. 'No routing' is a default value and any channel routing methods can be chosen by the user.

Muskingum: When the Muskingum method is selected. The user may enter various parameters to fit channel characteristics.




DT: Time interval

X: Dimensionless constant in a range of 0.0 - 0.5 that indicates the relative importance of the inflow and runoff contributed to the total storage

Y: Storage constant in the dimension of time (hour) that indicates the ratio of the storage to the runoff in the routing section

Muskingum Cunge: The Muskingum Cunge method's attribute window appears and the user can enter each parameter to fit to channel characteristics.



Muskingum Cunge	
Channel length	1000
Channel slope	0.005
Top width	15
Manning	0.03


Channel length: Channel length

Channel slope: Riverbed slope (dimensionless)

Top width: Top width of channel

Manning N: Manning's roughness coefficient

Kinematic wave: The Kinematic wave method's attribute window appears and the user can enter each parameter to fit channel characteristics. Computational demanding in running the model is required in the Kinematic wave method due to the effect of iteration for channel routing.



Kinematic	
Channel length	1000
Channel slope	0.005
Top width	15
Bottom width	10
Manning N	0.03
Channel depth	5

Channel length: Channel section length

Channel slope: Riverbed slope (dimensionless)

Top width: Top width of channel

Bottom width: Bottom width of channel


Manning N: Manning's roughness coefficient


Channel depth: Channel depth

3.12 Junction and Outlet


3.12.1 Junction

The function of Junction in DWAT model have two aspect. The first one is a simple junction to combine the flow from upstream. The second one, combined sewer, is a unique in DWAT model.

 The Junction node may be entered by selecting the icon shown in the following figure, placing it on an appropriate position in the 'Main Interface' with clicking the left button on a mouse.



If the Import node is left-clicked, a window to set the parameters related to the junction will appear.



Name: Name of Junction


Descript: Information of a junction may be entered.

Connect: Select node to water transfer (for example, treatment plant), it is used for combined sewer networks. The flow less than specified rate can be moved to selected node. Water quality module will be added in next version.


Maximum Q: The maximum flow rate to using **Connect**.

3.12.2 Outlet

The Outlet is a final exit of the system. Basically the Outlet node is similar to Junction except combined sewer function. The Outlet can be multiple. The Outlet node may be entered by selecting the icon shown in the following figure, placing it on an appropriate position in the 'Main Interface' with clicking the left button on a mouse.



If click the left mouse button, a window to set the parameters related to the outlet will appear.



Name: Name of Outlet node


Descript: Information of an outlet may be entered.

Chapter 4: Model Running


If all input data have been completed, now you are ready to run the model. In the chapter, matters related to the model run will be explained.

4.1 Analysis Condition Setting


If the 'Model' menu is selected in the main menu, the 'Model Setup' menu for selecting analysis conditions and running the model will appear as follows:




If the 'Model' menu is selected, a window for setting analysis conditions before running the model will appear as follows:



Title: This indicates a simulation title.


Term : A simulation period is needed to be selected. The total data period appears in the window and a user can define the simulation period. After clicking, the following date entry window will appear.



Interval: A user can revise a simulation time step for model run. The default unit is a second.

4.2 Model Execution

Once the analysis conditions have been set as above, the model is run by pressing 'OK' and selecting 'Run' in the 'Model' menu. Now, the model is ready to run. When 'Run' is pressed, the model will be executed.



Once 'Complete execute model' has appeared, press the 'Close' button.

Chapter 5: Analysis of Results

If all the executions have been completed, now you are ready to analyze the result. The DWAT enables users to freely compare outputs at each node, junction and link including hydrologic components. This configuration is very helpful to users in analyzing the results.

The DWAT basically has outputs of three types: water balance, graphs and tables. In this chapter, the methods to analyze the model results are explained in detail. The following Table 5.1 and Table 5.2 show summaries of the output parameters by source node that are created after executing the DWAT.

<Table 2.5-1> Output variables (catchment nodes)

Catchment node	Description of output variables
Inflow (m ³)	inflow volume
Rainfall (mm)	rainfall
Actual Evapotranspiration (mm)	actual evapotranspiration
Potential Evapotranspiration (mm)	potential evapotranspiration
Infiltrate (mm)	Infiltration
Soil moisture content (%)	current soil moisture content
Flow_surface (mm)	surface runoff
Flow_inter (mm)	interflow
Flow_groundwater (mm)	groundwater runoff
Recharge (mm)	groundwater recharge
Flow_total (mm)	total runoff
Groundwater Movement (mm)	groundwater movement
Groundwater Elevation (El. m)	groundwater level elevation


<Table 2.5-2> Output variable (Other node)

	Node	Description of output variables
	Inflow (m ³)	inflow volume
	Downstream Outflow (m ³)	mainstream discharge that did not flow into the pond
	Intake (m ³)	intake volume
	Evaporation Water surface (mm)	evaporation from water surface
Reservoir	Spillway Outflow (m ³)	overflow from spillway
	Pipe_Outflow (m ³)	discharge from outlet pipe
	Aquifer Loss (m ³)	loss from bottom of the pond
	Volume (m ³)	storage volume
	Water Level (m)	water level
	Inflow (m ³)	inflow volume
	Bypass Volume (m ³)	high flow bypass during flood season
	Evaporation Water surface (mm)	evaporation from water surface
Wetland	Spillway Outflow (m ³)	overflow from spillway
	Pipe Outflow (m ³)	discharge from outlet pipe
	Aquifer Loss (m ³)	loss from bottom of the pond
	Volume (m ³)	storage volume
	Water Level (m)	water level
	Inflow (m ³)	inflow volume
	Intake (m ³)	intake volume
Recycle	Downstream Outflow (m ³)	downstream discharge after intake
	water supply node name	node name that receive supplied water
Import	Water Supply (m ³)	water supply from outside

5.1 Water Balance

The results of water balance in a watershed may be viewed based on two methods. The first is to view the results in the main menu and it is shown in the following figure. The second is to view the results at each sub-catchment node in the catchment node configuration screen of the 'Main Interface'.

Pressing 'Model' > 'Water-balance' menu in the main menu.



The 'Water balance' window displays a table with the following data:

	Average	Catchment	2002	Catchment 9	Catchment 7	Catchment 3	Catchment 11	Catchment
Rainfall	1231.7	1231.7	1231.7	1231.7	1231.7	1231.7	1231.7	1231.7
Inflow	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
ET	131.2	62.5	131.2	93.9	51.3	237.0	56.9	10
ET_imp	19.7	18.7	1.4	53.1	18.7	0.0	33.0	1
ET_per	111.4	43.7	255.6	40.8	32.6	237.0	23.9	8
Runoff	975.1	1022.9	933.4	954.6	875.3	937.2	697.0	105
Surface	176.6	141.4	126.1	402.5	141.4	118.0	250.2	13
Interflow	271.2	536.2	241.9	80.2	264.0	239.9	136.0	29
Groundwater	527.3	345.3	565.4	471.9	469.9	579.4	310.8	63
Recharge	439.0	247.7	474.6	372.8	369.9	479.7	210.9	56
Soil	-2.46357	-2.38776	-3.42949	-1.01739	-1.47902	-2.92595	-1.25662	-3.036
GW-Storage	-88.31232	-97.56055	-90.72383	-99.13438	-99.92149	-99.67852	-99.92617	-65.394
MassBalance	216.18462	246.38016	135.49123	283.40039	406.49600	160.12206	578.97076	135.518

By year: This is a tab to control output formats. Analysis results are displayed on an annual basis. As shown in the above figure, each hydrologic component is displayed on the left side and water balance is displayed by node on the right side along with average value.

By node: This is a tab to control output formats. Analysis results are displayed by sub-catchment. As shown in the following figure, each hydrologic component is displayed on the left side and resultant values are displayed on the right side on an annual basis.

Water balance


By year By node Node: Catchment 1 Sum
Catchment 1
Catchment 2
Catchment 9
Catchment 7
Catchment 3
Catchment 11
Catchment 5
Catchment 4
Catchment 10
Catchment 8
Catchment 6 Select: Outlet

	Average	2002	2003	2004	2005	2006	2007
Rainfall	1346.5	1231.0	1197.0	1217.0	1427.7	1362.7	1325.0
Inflow	0.0	0.0	0.0	0.0	0.0	0.0	0.0
ET	54.4	62.0	48.5	48.5	43.0	43.7	71.8
ET_imp	20.0	18.0	18.8	18.8	18.5	17.9	22.8
ET_per	34.3	43.0	29.7	29.7	24.5	25.7	49.0
Runoff	1039.3	1022.0	916.4	916.4	1103.2	1045.5	990.1
Surface	155.0	141.4	173.5	139.4	167.1	159.2	149.5
Interflow	581.9	536.2	699.4	499.2	593.4	607.6	555.5
Groundwater	302.4	345.3	284.9	277.8	342.8	278.7	285.1
Recharge	286.4	247.7	284.5	284.5	338.1	283.5	280.2
Soil	-0.46505	-2.38776	-2.39868	2.07700	0.66873	-3.81773	3.06816
GW-Storage	-16.03515	-97.56055	-0.39688	6.68672	-4.76367	4.79805	-4.97461
MassBalance	269.29692	246.38016	302.92104	243.40207	285.53765	272.53837	265.00221


Close

Select: This is to select the outlets of a catchment. If the catchment has many outlets, the results on the water balance may be identified for each catchment outlet.

In the second method for viewing water balance results, water balance may be viewed by right-clicking on each sub-catchment node as mentioned above. However, the water balance output from sub-catchment nodes does not provide information on the entire water balance, but rather provides only the resultant water balance of the relevant sub-catchment. Right-clicking on the sub-catchment node and clicking the ‘Water balance’ menu.



The following window will appear.




Year: The relevant year may be selected. As shown in the above figure, the water balance results at hydrologic component may be identified by clicking each relevant year.



5.2 Chart

Analysis results are shown in various forms of graphs in the DWAT. As with the above water balance results, there are two methods to view graphic results on the entire catchments. Graphic results for individual sub-catchments, links, junctions and outlets can be viewed by the setting tab of the left window, no matter which method the user selects to view the results. The method to check results in the main menu is as follows:


- Select 'Model' > 'Chart' in the main menu.
- Right-clicking on the sub-catchment node and clicking the 'Chart' menu.




A Chart result window will appear.



: This is a project selection window. In 'Current', the results of the current project may be viewed. When the plus button is selected, the results of other projects are opened and displayed for comparison. That is, a function to compare the result of the current project with those of other projects is provided.





: This attribute window shows the information of each node, junction, link and outlet of the relevant project.



: This is located below the node attribute window and shows the field attribute window. They are the output parameters mentioned earlier in Tables 5.1 and 5.2. The user can select the relevant

sub-catchment or the link and junction through the node attribute window and then select output variables in the field attribute window to see graphic results.

The user may press the ‘Add’ button to display the graphic results when the sub-catchment and output variable have been selected. It is shown in the following figure.



: The left bottom window displays the names of the currently output variables. The user may also select multiple nodes and output variables and display them simultaneously on the same screen. If the user wishes to delete some output items from the graph, the user may click on the item or right- click the button and select ‘Remove’. If the user wishes to delete all items, the user may just select the ‘init’ button. In addition, the interested region in the graph may be expanded by using the dragging function of the mouse. Once expanded, the region may be moved using the scroll bar on the bottom of the graphic result. The user can go back to the entire view by pressing the ‘Zoom


All' button. The form of an expended graph is as shown in the following figure.

5.3 Table

The DWAT contains a function to view result values in the form of tables at all nodes, junctions, links and outlets.

Unlike water balance and graphic results, table results can be viewed only through right mouse clicks on the nodes, links and junctions of the main screen. In addition, information on all nodes cannot be seen, and only the results for individual node are outputted. That is, the result field of tables is the output parameter and each output parameter is as shown in Tables 5.1 and 5.2.

The following window appears by right-clicking on a node in the configuration screen of the main interface.



When the 'Table' menu has been selected, the following table result window is displayed. As shown in the figure, the names of the output variable for each time series appear on the top and time series data are displayed.

	Date	Inflow(S@)	Rainfall(mm)	Actual	Potential	Flow Surfa	Flow Interf	Flow Groun	Flow Totalf	Infiltratefmm	Rechargef(m	Groundwate	Soil	Groundwate
1	02/01/01 00	0.00	0.00	1.12	2.90	0.00	0.00	2.74	2.74	0.00	0.00	0.00	0.21	34.97
2	02/01/02 00	0.00	0.00	1.13	2.93	0.00	0.00	2.67	2.67	0.00	0.00	0.00	0.16	34.95
3	02/01/03 00	0.00	0.00	0.00	1.60	0.00	0.00	2.59	2.59	0.00	0.00	0.00	0.16	34.92
4	02/01/04 00	0.00	0.00	0.00	1.94	0.00	0.00	2.52	2.52	0.00	0.00	0.00	0.16	34.89
5	02/01/05 00	0.00	0.00	0.00	2.89	0.00	0.00	2.45	2.45	0.00	0.00	0.00	0.16	34.87
6	02/01/06 00	0.00	0.00	0.00	2.13	0.00	0.00	2.39	2.39	0.00	0.00	0.00	0.16	34.85
7	02/01/07 00	0.00	2.60	0.00	2.53	0.14	0.00	2.32	2.46	1.43	0.00	0.00	0.22	34.82
8	02/01/08 00	0.00	0.00	1.48	2.68	0.00	0.00	2.26	2.26	0.00	0.00	0.00	0.18	34.90
9	02/01/09 00	0.00	0.00	0.03	1.72	0.00	0.00	2.19	2.19	0.00	0.00	0.00	0.18	34.78
10	02/01/10 00	0.00	0.00	0.00	1.35	0.00	0.00	2.13	2.13	0.00	0.00	0.00	0.18	34.76
11	02/01/11 00	0.00	0.00	0.00	1.91	0.00	0.00	2.08	2.08	0.00	0.00	0.00	0.18	34.74
12	02/01/12 00	0.00	0.00	0.00	1.54	0.00	0.00	2.02	2.02	0.00	0.00	0.00	0.18	34.72
13	02/01/13 00	0.00	0.00	0.00	2.00	0.00	0.00	1.96	1.96	0.00	0.00	0.00	0.18	34.70
14	02/01/14 00	0.00	0.70	0.00	2.11	0.00	0.00	1.91	1.91	0.39	0.00	0.00	0.19	34.68
15	02/01/15 00	0.00	8.80	0.46	0.84	1.66	1.01	1.86	4.53	4.84	2.02	0.00	0.25	34.68

References

- Arnold, J.G., Williams, J.R., Nicks, A.D., and Sammons, N.B., 1990, SWRRB: A Basin Scale Simulation Model for Soil and Water Resources Management, Texas A&M Univ. Press, College Station, TX.
- Beston, R. P., "What is watershed runoff?" *Journal of Geophysical Research*, 69, pp.1514-1551, 1964.
- Brigham Young University, 2002, Watershed Modeling System (WMS) Tutorial, Environmental Modeling Research Laboratory.
- Chow, V.T., Maidment, D.R., and Mays, L.W., *Applied hydrology*. McGraw-Hill, 1988.
- Chu, S.T., "Infiltration during an Unsteady Rain." *Water Resources Research*, Vol. 14, No. 3, pp. 461-466, 1978.
- Cunge, J.A., 1969. On the subject of a flood propagation method (Muskingum method). *Journal of Hydraulic Research* 7(2), 205–30.
- Dawdy, D.R., and O'Donnell, T., "Mathematical Models of Catchment Behavior." *Journal of Hydraulics Division, Proceedings of the ASCE*, pp. 123-136, 1965.
- DeVries, J. J. and T. V. Hromadka, "Chapter 21 Computer Models for Surface Water," in *Handbook of Hydrology* (D.R. Maidment, Ed.), McGraw-Hill, 1993.
- DHI, 1999, MIKE SHE Water Movement: User manual, Denmark: Hørsholm, Danish Hydraulic Institute.
- Downer, C.W., and F.L. Ogden, 2002, GSSHA - User's Manual, Engineer Research Development Center.
- Ferguson, B.K., *Stormwater Infiltration*. Lewis Publishers, CRC Press Inc., Boca Raton, Florida, pp. 269, 1994.
- Green, W. H., and Ampt, G. A., 1911. *Studies in Soil Physics, I: The Flow of Air and Water through Soils*. *Journal of Agricultural Sciences* 4:1-24.
- Horton, R. E., "The role of infiltration in the hydrologic cycle," *American Geophysical Union, Transaction*, 14, pp.446-460.
- Huber, W.C., and Dickinson, R.E., *Storm Water Management Model, Version 4: User's Manual Ver. 2.1*. USACE, 1988.
- Jia, Y., Ni, G., Kawahara, Y., and Suetsugi, T. (2001). "Simulation of hydrological cycle in an urbanized watershed and effect evaluation of infiltration facilities with WEP model." *Journal of Hydroscience and Hydraulic Engineering*, Vol. 19, No. 1, pp. 43-52.
- John Could, Erik Nissen-Petersen, *Rainwater Catchment Systems for Domestic Supply*, Intermediate

- technology publications, 1999.
- Klaus W. Koenig, The Rainwater technology handbook-Rainharvesting in building, Wilo-Brain, 2001.
- Kresin, C., Long-Term Stormwater Infiltration through Concrete Pavers. M.Sc. thesis, University of Guelph, Guelph, Ontario, Canada, 1996.
- Mein, R.G., and Brown, B.M., "Sensitivity of Optimized Parameters in Watershed Models." Water Resources Research, Vol. 14, No. 2, pp. 299-303, 1978.
- Mein, R.G. and Larson, C.L. (1973). "Modeling Infiltration During a Steady Rain.", Water Resources Research, Vol. 9, pp. 384-394.
- Ponce, V.M., Engineering Hydrology - Principles and Practices. Prentice Hall, 1988.
- S. Hereth and K. Kusiake, Simulation of Basin Scale Runoff Reduction by Infiltration Systems, Wat. Sci. Tech., Vol. 29, No.1-2, pp.267-276, 1994.
- S. L. Neitsch, J. G. Arnold, J. R. Kiniry, J. R. Williams, Soil and Water Assessment Tool (SWAT) Theoretical Documentation, 2001.
- Takahashi Asano, "Handbook of Wastewater Reclamation and Reuse", Water Quality Management Library, 1998.
- V. P. Singh, Computer Models of Watershed Hydrology, Water Resources Publications (USA), 1995.1.
- Wooding, R.A. (1965). "A hydraulic model for the catchment-stream problem, I. Kinematic-wave theory." Journal of Hydrology, Vol. 3, pp. 254-267.